

Product summary

DiSEqC multiswitch with external power supply, switchable active/passive terr. input

Brief description

17in/30out standalone multiswitch for distribution of terrestrial and satellite signals from 4 satellite positions (16 polarities) to 30 users. The multiswitch is DC supplied from connected satellite receivers. Power from external supply is through socket DC 2.1 interconnected to all inputs.

Avoid short circuit at TERR input!

Using a rotary trimmer, it is possible to switch terrestrial band from active to passive mode.

For use with Quattro LNB only!

Power supply is included in the package.



Technical data

Parameter	Condition	Value
Frequency range	LNB inputs	950-2150 MHz
	Terr. Inputs	40-862 MHz
	Outputs	40-2150 MHz
Control		DiSEqC 1.0 (2.0) commands
Insertion loss	Sat.	5 dB avg
	Terr. active / passive	12 / 30 dB avg.
Sat. inputs isolation	Between V/H polarisations	20 dB min
	Between low/high bands	25 dB min
	Between sat. Systems	25 dB min
Maximum input level*	Sat./Terr.	105 / 105 dBμV
Maximum user output level*	Sat./Terr.	100 / 93 dBμV
Current consumption	Per user output	90 mA (18V)
Dimensions (w,d,h)		18.6 x 33 x 5.1 cm
Temperature range		-25 ~ +60 °C
Weight		1.050 kg

Postal address: EMP-Centauri s.r.o. 5. května 690 339 01 Klatovy Czech Republic

Management: Tel.: +420 376 323 813 Tel.: +420 603 497 419 E-mail: info@emp-centauri.cz

Sales department: Tel.: +420 376 323 813 Tel.: +420 603 497 419 Tel.: +420 776 619 976 (EN) Tel.: +420 778 066 654 (CZ) E-mail: sales@emp-centauri.cz

Purchase department: E-mail: purchase@emp-centauri.cz

Technical support: Tel.: +420 376 323 853 (during workhours) Hotline: +420 603 497 419 (available anytime) E-mail: support@emp-centauri.cz Skype ID : **live::cid.624e3941fb5334d9**